

HOW TO GUIDE



Kingfisher Building Products Ltd
Cooper Lane
Ulverston
LA12 9RA

T: +44(0)1229 869 100
F: +44(0)1229 869 101

www.kingfisheruk.com

- 1 REMOVE LOOSE PAINT**
- 2 NEUTRALISE MOSS & MOULD**
- 3 MAKE GOOD POINTING**
- 4 REPAIR WEATHERED BRICKS OR STONE**
- 5 STABILISING & PRIMING**
- 6 APPLY WEATHERFLEX PAINT**



RE-COAT YOUR HOME

Important! Kingfisher "How To" guides offer a step-by-step overview showing you how the products can be used together to tackle various projects but they should always be read in conjunction with the individual "Product Data Sheet" to familiarise you with specific application details for each product. Always refer to the "Material Safety Data Sheet" before use. The data sheets can be obtained at www.kingfisheruk.com or by calling 01229 869 100.



RE-COAT YOUR HOME

P. 01229 869 100

E. technical@kingfisheruk.com




First impressions count and maintaining your home's exterior in good decorative order really matters, not just from the perspective of "value" but also because the condition of your masonry coating often determines the condition of the very fabric of your home. This is because your masonry coating is a shield against the elements, a first line of defence against moisture ingress, the enemy of all buildings. Consequently an effective and lasting re-coating needs to be tackled systematically, and this "How to" guide will show you the 6 simple steps to getting it right. As with most coatings, good preparation is the key to success!

1

REMOVE LOOSE PAINT

SUGGESTED PRODUCT - HARRIS JUMBO WIRE BRUSH



Remove all existing loose paint either chemically with paint stripper or with a wire brush and scraper to make sure that you have a sound surface onto which to apply the "Weatherflex". It is not necessary to remove all existing paint – that which is still well bonded to the surface will normally provide an adequate base for "Weatherflex".



RE-COAT YOUR HOME

P. 01229 869 100

E. technical@kingfisheruk.com



2

NEUTRALISE MOSS & MOULD

SUGGESTED PRODUCT - KINGFISHER BIO-WASH

Where green mould, lichens and moss have taken hold, spray or sponge thoroughly with Kingfisher “Bio Wash” to kill off the visible “green stuff” and also the invisible roots and spores which are embedded in the substrate. This is very important and will prevent re-growth underneath your new coating.



3

MAKE GOOD POINTING

SUGGESTED PRODUCT - KINGFISHER POINTING MORTAR & POINTING SOLUTION

Carefully examine the mortar joints for signs of decay and rake out any crumbly areas and re-point adding Kingfisher “Pointing Solution” to the mix for waterproofing, flexibility and adhesion. Pay special attention to repair of chimney stacks as these are a frequent source of moisture ingress. Phone us if in doubt.



4

REPAIR WEATHERED BRICKS / STONE / RENDER

SUGGESTED PRODUCT - KINGFISHER POINTING SOLUTION

If there are any “blown” brick faces or stones, these can be “faced up” as follows:

A. Priming Mix. In a bucket mix ONE part sharp sand, ONE part ordinary cement with “Pointing Solution” mixed 1:1 with water. This should be paddle mixed with a drill (400 to 600 rpm) until a “yoghurt consistency” is achieved. You then brush or stipple this grey primer onto the area with a masonry brush or similar. Leave this for around 20 to 30 minutes.

B. Repair Mix. Mix up a stiff repair render of 1 part cement to 4 parts sand mixed with “Pointing Solution”. It is important to apply the repair render within half an hour of the primer mix to ensure “continuity of key”. This method avoids the usual shrinkage cracks and “falling out”.



RE-COAT YOUR HOME

P. 01229 869 100
E. technical@kingfisheruk.com



5

STABILISING & PRIMING

SUGGESTED PRODUCT - WEATHERFLEX STABILISING SOLUTION

Where stone, brick or mortar may be slightly friable or “soft”, such surfaces should be primed with “Weatherflex Stabilising Solution” to harden the surface and improve the adhesion of the “Weatherflex” coating. The same treatment should be used for “dusting” surfaces and flaking paint which cannot be adequately removed by wire brushing. **IMPORTANT!** “Weatherflex Stabilising Solution” must be applied to any new pointing or re-facing repairs prior to coating with “Weatherflex” to prevent the alkalinity in the mortar from discolouring the paint (because although mortar hardens within 24 hours, it takes up to two months for full chemical cure!).



Where the wall substrate is non-porous in nature (e.g. engineering bricks or granite stone) you should apply “Weatherflex Stabilising Solution” to improve adhesion. If in doubt a small test area of both stabilising solution and paint should be applied to check compatibility with the surface and if possible left to weather. Note: This is especially important if there is a possibility that the surface might previously have been treated with a clear water repellent or similar.

6

APPLY MASONRY PAINT

SUGGESTED PRODUCT - WEATHERFLEX SMOOTH OR TEXTURED MASONRY PAINT

“Weatherflex” requires 2 coats and can be applied by brush or roller. Apply with broad, even strokes and avoid “loading” the brush or roller, especially on the first coat. It can be spray applied with professional airless sprayer (e.g. Graco) at a pressure of 2200-2500 psi. It is recommended to coat one elevation at a time and check the batch numbers, ensuring that tubs from the same batch number are matched up for the top coat or at least per elevation. Do not apply in temperatures below 8 degrees C or if rain is expected within 12 hours. Always buy a tester pot to check the colour suitability **BEFORE** ordering the full size container(s).



IMPORTANT!

Kingfisher “How To” guides offer a step-by-step overview showing you how the products can be used together to tackle various projects but they should always be read in conjunction with the individual “Product Data Sheet” to familiarise you with specific application details for each product. Always refer to the “Material Safety Data Sheet” before use. The data sheets can be obtained at www.kingfisheruk.com or by calling 01229 869 100.